


HOW TO CHECK THAT THE WIRING IS CORRECT BEFORE FITTING A DYNALITE.

(NEGATIVE EARTH ONLY)



WARNING

AT ALL TIMES WHILE TESTING THE WIRING AND FITTING THE DYNALITE PLEASE MAKE SURE THAT THE D+ WIRE IS WELL INSULTED AND DOES NOT COME IN CONTACT WITH ANYTHING.

